

1056-0002 1936-1984 Big-Twin

- 1) 1-1057-0012 bearing adaptor
- 2) 1-1018-0015 bearing
- 3) 1-1101-0066 large snap ring
- 4) 1-1101-0068 small snap ring
- 5) 1-1057-0013 steel lock ring
- 6) 6-1100-0131 screws for lock ring
- 7) 1-2061-0003 steel inner hub
- 8) 1-1061-0012 aluminum outer hub (1.712")
- 9) 2-1100-0033 screws for clutch hub
- 10) 4-1100-0113 bolts for clutch hub
- 11) 4-2057-0026 nuts for clutch hub screws
- 12) 1-2057-0030 special clutch hub nut & seal
- 13) 7-1054-0006 friction clutch plate
- 14) 7-2060-0006 steel clutch plate (.047")
- 15) 1-1060-0003 steel clutch plate (.120") rear
- 16) 1-2058-0001 pressure plate (aluminum)
- 17) 1-2059-0003 diaphragm clutch spring (medium)
- 18) 1-2057-0005 clutch adjustment screw
- 19) 1-1057-0004 adjustment screw lock-nut
- 20) 2-1058-0106 locking clips
- 21) 1-2059-0200 diaphragm spring retainer
- 22) 4-1057-0015 shouldered nuts for retainer
- 23) 1-2057-0024 washer set (4-and-4)

