



RECOMMENDED CLUTCH CABLE ADJUSTMENT

1. Turn the center clutch adjusting screw out away from contacting the main/shaft pushrod.
2. Loosen the clutch cable adjuster and back out the cable adjustment until the clutch lever is resting against the handlebar grip.
3. Turn the center adjusting screw in until the clutch handlebar lever starts to move away from the handlebar grip.
4. Now back-off the adjusting screw 1/4 of a turn and re-tighten the adjusting screw lock nut.
5. Adjust the clutch cable to approximately 1/8" free play from the cable ferrule to the clutch perch if using a black vinyl cable. If using a braided cable you will have very little free play if any at all.

American Prime Manufacturing Inc.
8205 Secura Way
Santa Fe Springs, CA 90670
www.americanprimemfginc.com